







Introducing Gulfstream's newest, most luxurious and sophisticated unit yet, combining elegance with the Universal Induction IDJET System.

A beautifully contoured pedicure base linked together with a stimulating massage chair giving your clients a pampered worry-free pedicure experience.

A wonderful experience for both client and technician.









Toll Free. 1.877.622.4853 www.gulfstreaminc.com

LAMIRA

Introducing Gulfstreams versatile and universal new footrest.

Each pad can be lifted, turned and used in many different positions.

The revolutionary 360-degree footrest enhanced for the customers' satisfaction.

It offers options according to your interest with its gold and chrome models.







FULLY UPGRADED MASSAGE SYSTEM

More personalized massage techniques, such as kneading, knocking, flapping, shiatsu and synchronous kneading and flapping.



M A S S A G E E X P E R T





HUMAN VERTEBRAE TRACKING TECHNOLOGY

OLD STYLE TRADITIONAL TRACKING

Only makes straight rail massage according to the given position. Does not fill the dorsal cavities of the body, and gives an uncomfortable feeling.



HUMAN VERTEBRAE

CONTOURS TRACKING TECHNOLOGY

BY GULFSTREAM

Combined with ergonomics design, fixed point massage. Help to maintain the "S" shape of the curve of human vertebrae. Relax the spine and relieve tense muscles.



- Innovatively integrating air suspension technology, promoting the upgrade of massage quality.
- Say goodbye to the rough massage feeling. Feel more flexible and more sensitive touch.
- More flexible tracking.
- Let the body genuinely enjoy the art of massage.

FEATURES OF FUNCTIONAL POINTS

More Personalized Overall Design













your seat with its large Acetone-Proof tray.

REMOTE CONTROL AND MOVEMENT OF THE CHAIR.

Detailed and clear operating interface to achieve the orderly realization of various functions.



1999					
(Q)	To start	To start or stop massage of the upper body			
	To carrying on automatic massage around the neck shoulder mainly				
	Carry or mainly	automatic massage around in carrying the waist			
	different	Adopt the various tactics to carry on automatic massage to different position of the upper part of the body, the massage position covers the whole upper part of the body.			
Method	Knead	O Flap O Knock Knead O Knock & Flap O Press			
	Flap	O Knesd ● Flap O Knock & Flap O Press Speed, Width			
	Knock	O Flap O Flap Finock Kneed O Press Speed, Width			
	Press	O Kneed O Flap O Knock & Flap O Press Speed, Width			
	Kneading & Flapping	O Knead O Flap O Kneck Kneed O Kneck & Flap O Press			
	Massage modes are equipped with 5 strengths.				
Intensity		For speed and massage treatments • 1 • 1 0 1 0 1 0 1 selection. five intensity options available. the indicators are as follows(black stands • 1 • 1 0 1 0 1 0 1 • 1 0 1 0 1 • 1 0 1 0 1 • 1 0 1 0 1 • 1 0			
Width	•	Width:when massage treatment of flapping,shiatsu, or knocking has been chosen,press this button to adjust the width of the massage hands,three options,not available under auto kneadingstate.			

Roller Position	\bigcirc	When fixed massage has been chosen, press this button to move the massage device downward to suit precise massage points, not available under auto state.	
		When fixed massage has been chosen, press this button to move the massage device upward to suit precise massage pointsm, not available under auto state.	
Back Stretching	(†)	Upper body(overall) trip massage	M
		Small area(partial) trip massage	<u>Ľí</u>
		Fixed position (fixed) massage	<u></u>

		Fixed position (lixed) massage	
Timing	(V)	Three modes of timing: 10 mins, 20 mins a	and 30 mins.
Air	(6)	Turn on or turn off buttock air pressure ma options available.	ssage, 2 modes

Intensity	2 intensity options available.

Seat	Forward	Press this button continually and the seat frame will move forward, loose your finger and the movement will stop.
	Backward	Press this button continually and the seat frame will move backward, loose your finger and the movement will stop.
Back	Back Recline	Press this button continually and the backrest frame will move upward, loose your finger and the movement will stop.
	Back Up	Press this button continually and the backrest frame will move downward, loose your finger and the movement will stop.



WATERDANCE"













Toll Free. 1.877.622.4853 www.gulfstreaminc.com IDJET®, Waterdance®, Gulfstream Inc.® are trademarks of Gulfstream Inc.
All products are Patented. © 2022 All rights reserved.
Design and Specifications are subject to change without notice.





Toll Free. 1.877.622.4853 www.gulfstreaminc.com IDJET®, Waterdance®, Gulfstream Inc.

All products are Patented. © 2022 All rights reserved.

Design and Specifications are subject to change without notice.